





Please refer to our videos at www.casperscreens.com/videos for more installation information.

STEP 1. Install the handles by sliding the tabs on each handle into the handle channel on both sides of the pull bar, which is attached to the mesh, with the Casper logo facing you. (See Diagram 1) Slide the handles to the center of the housing.

STEP 2. Insert a boot into each end of the pull bar. You will want to use a crimping tool or pliers to crimp the end of the pull bar slightly, **BEFORE** inserting the boot to ensure a snug fit to prevent them from coming loose during use. (See Diagram 2)